

Notes on Fitting

Your door is supplied with all hardware and door furniture pre fitted. If applicable, some door furniture is removed just before leaving our workshop and will be packed separately to avoid any damages during transport.

All our doors are pre hung and tested in our workshop and have to pass our quality control procedures before leaving our workshop, so it is very important that your door is fitted properly at your end to ensure smooth operation. The following notes are important during fitting:

- The frame needs to fit completely square and level in the structural opening.
- If side glass is ordered, it will be supplied with the glass and the beading semi fitted. These will have to be removed during installation to be able to screw the frame to the side wall behind the glass. Before refitting the glass ensure that the yellow removable part of the glazing tape is removed from both the tape on the frame and the tape on the beadings. Fit the glass in place and use spacers if applicable, before fitting the loose beading, run a line of glazing mastic or exterior grade clear silicone all around the glass (between the glass and the frame making sure to remove any excess from the glass to allow for the glazing tape on the beadings to stick). Fit the beading and attach to the frame, preferably using a pin gun.
- Where possible, screw in the frame to the wall by locating the screws behind hinges and lock keep plates.
- Fit the door leaf into the frame and check if the door is operating smoothly. If not, check if the frame is square and level and adjust accordingly. If your order includes adjustable hinges, these can be adjusted 3 dimensionally after installation.
- It is recommended to apply the first coat of finishing material before installation, particularly the areas that are inaccessible after installation (under hinges, locks, backplates, etc). As soon as your door is installed, it will need to be finished in accordance with our coating information (Enclosed). Failing to do so, might cause the wood to absorb moisture and maybe even cause long term damage to the wood. If your door is exposed, you will need to provide cover until the coating material is fully dry.
- It is recommended to remove any door furniture before applying the finishing material.
- If your door includes stainless steel, please make sure this is covered with low tack masking tape to avoid staining it. If any of the finishing material touches the stainless steel, this is best removed before it dries with methylated spirits without making contact with the wood.

For further information please contact our office on 0870 609 1525 or email us on info@urbanfront.co.uk.